



MT500 3-PHASE CONVERSION REGULATOR CONNECTION GUIDE



Male Generator Tab:

Use Jeweller's screwdriver to press the tab to release from housing



New Generator Wire