



Type A

Positive and negative markings
next to the terminals.



Type B

Positive terminal has a plastic surround.
Negative is a plain terminal.



DRG: HT Ignition Coil Connection

Report errors to drawing office. Do not scale.