

# Rex's XT500 Wiring Options

Order code: WLK-1








For all points ignition models.

Does not work with factory CDi  
(USA models G&H 80-81)

Due to a multitude of wiring variations on XT500 we no longer supply parts for each variation. Our wiring kit takes away all the guess work and problems with different variations and switch compatibility issues on points ignition models. Comprises New wiring loom, LH handle bar switch & new ignition switch.

## Switch & Wiring Loom Compatibility

Handle bar switch	Handle bar switch connectors	Wiring loom & Ignition switches
<div>HBS-1 XT500 76-78</div> <div></div> <div>Look at wire end of connector</div> <div></div> <div>Male Bullets</div>	<div>Switch side:</div> <div>7-4WM-2.3 7-6WF-2.3 TK2 (10 complete bullets)</div> <div>Opposite connectors:</div> <div>TK5 7-4WF-2.3 7-6WM-2.3 TK2 (10 complete bullets)</div>	<div>Use with:</div> <div>WL-26</div> <div><b>Ignition switch IGN-6</b> Fits XT500 76-77 – Also USA G&amp;H 1980-81 with factory CDi ignition.</div> <div>Ign Opposite Connectors: 7-4WF-2.3</div>
<div>HBS-2 XT500 79-85</div> <div></div> <div>Look at wire end of connector</div> <div></div> <div>Female Double Bullet</div> <div></div> <div>Male Bullets</div>	<div>Switch side:</div> <div>7-6WM-2.3 TK2 (10 complete bullets) 1 X double female</div> <div>Opposite connectors:</div> <div>7-6WF-2.3 TK2 (10 complete bullets)</div>	<div>Use with:</div> <div>WL-27</div> <div><b>Ignition switch IGN-3</b> XT500 1977-85.</div> <div>Ign Opposite Connectors:  7-6WF-2.3 7-4WF-2.3</div>

Please check carefully what is on your machine as year/model and the market and to which the machine was first supplied causes differences. Fitting is for guidance only between handle bar/ ignition switches & wiring loom versions and is not intended as definitive for all models, there are known to be many variations in the XT500 wiring. We recommend making detailed notes and diagrams.